



Type C 2SP remote controller

REF 819756/819757



The **type C 2-speed remote controller** is a safety device for controlling air flow regulation at low and high speed depending on the position of the sash.

A speed sensor is used to determine the flow rate. Audible and visual alarm is set off in case of insufficient speed or too high sash height and other malfunctions. The controller engages the second gear by means of a contactor placed in the path of the sash.

The remote HMI is used to control the fume cupboard ventilation and to carry out the following adjustments on site.

This controller complies with EN 14175 and RoHS Standards.



Table of contents

1. Presentation	3
1.1. HMI (Human Machine Interface)	3
1.2. CPU (Central Processing Unit)	3
1.3. Schematic diagram	4
1.4. Connector specifications	5
2. Installation and mounting	6
2.1. Dimensions	6
2.2. Positioning on the fume hood	7
2.3. Cutting template	8
2.4. Installation tips	9
3. Wiring diagram	10
4. Adjustment procedure	11
5. Factory rest.....	13
6. Test mode.....	13
7. Change the audible alarm delay.....	14
8. Error messages (digital display option)	14
9. FAQ.....	14
10. Maintenance.....	15
11. Warranty.....	15







1. Presentation

The remote **type C 2SP remote controller** consists of a small HMI, easily installed on a fume hood, and a central processor.


1.1. HMI (Human Machine Interface)



1.2. CPU (Central Processing Unit)



1.3. Schematic diagram



The remote **type C 2-speed** controller is used to control the airflow of a fume hood.

Pressing the ventilation ON/OFF button on the remote HMI closes the two relays VENT 1 and 2, which unlocks the drive. The controller then sends a 0/10v signal that the drive will interpret in order to change the motor rotation speed and the flow rate. This is a **two-speed** controller: the CPU sends a fixed voltage when the sash is low and another fixed voltage when it is high.

A speed sensor permits to measure whether the suction flow is sufficient (≥ 0.4 m/s) and indicates the ventilation status by a green and red LED.

The front panel allows you to control the operation of the fume hood and in particular:

- An ON/OFF for lighting
- An ON/OFF for ventilation
- An alarm stop button




1.4. Connector specifications


Power supply	Electrical transformer 230v/12v 500mA. (delivered with)
VENT1/FAN1	ON/OFF Ventilation relay driving by  Disconnection voltage: 120v Disconnection current: 0.5 A
VENT2/FAN2	Same VENT1
0/10v	0/10v output which returns a voltage according to the speed measured by the sensor. This output must be sent to the frequency inverter.
LIGHT	ON/OFF lighting relay driving by  Disconnection voltage: 220v Disconnection current: 3 A
ALARM	Relay controlled by alarm activation. Normally open contact Disconnection voltage: 120v Disconnection current: 0.5 A
SASH Open	Sash contact which triggers a visual and audible alarm.
IDLE	Sash Contact which toggles from low speed to high speed.

2. Installation and mounting

2.1. Dimensions



HMI



CPU


Speed sensor

2.2. Positioning on the fume hood

You can install the CPU in the false ceiling of the fume cupboard.



The controller is delivered with a 2,5 meters cable.



- Vertical HMI are usually attached to the side frame of fume hoods.
- Horizontal HMI's can be set at the user's convenience.
- The 2nd gear contact is installed approximately 150mm above the work surface.
- The sash contact must be fixed so that it sets off when the sash exceeds 400mm or 500mm.



To comply with EN 14175 standard, you must install a sash contact.


Where to install the speed sensor?

The speed sensor must be positioned on the fume hood ceiling in one of the two positions shown in the diagram.

These locations must be respected so that the probe is accurate.


Drill a 22mm diameter hole and put the speed sensor in it.

An adhesive is provided on the sensor to fix it correctly to the fume hood and prevent leaks.




2.3. Cutting template

If you want to install your fume hood controller without the surface bow mounting, you will need to make the following cuts:




2.4. Installation tips

- Do not install the sensor on the extraction tube above the fume hood
- Avoid installing the sensor in a dead zone of the fume cupboard
- The probe must pass entirely through the fume cupboard ceiling. Otherwise, you must use a 25mm PVC tube to extend the outlet.
- A speed of 0.2 m/s minimum must be measured through the sensor to ensure proper operation.
- When adjusting the controllers, it is necessary that:
 - The fans are running
 - The laboratory is completely closed (doors, windows, etc.)
 - Have an anemometer
- Pay attention to motor connections (star or delta)





3. Wiring diagram





4. Adjustment procedure

This controller requires a 0/10v setpoint setting for low and high speed and a display setting in case you have the display option.

Low speed adjustment


- 1 Switch on ventilation with
- 2 Put the sash in down position. Wait 15 seconds for the speed to stabilize
- 3 **Enter the setting mode:** Press and hold for at least 3 seconds on release and then press and simultaneously on and shortly. The beep will then sound twice, and the red LED will flash. You are in the setting mode. If you have the display option, the screen will display the voltage that the controller is communicating.



- 4 Press on to increase the speed
Press on to decrease the speed

Once the anemometer measures a speed ≥ 0.4 m/s, the 0/10v setpoint is adjusted.

Each press increments the setpoint voltage by 0.5V over a range of 0.5V to 10V.




A press on increase the 0/10V reference sent to the drive.

A press on decrease the 0/10V reference sent to the drive.


- 5 To validate the low speed setpoint and exit the adjustment mode, press and hold down .
- The low speed is set, now you have to set the high speed.

High speed adjustment

- 6 Put the sash in the upper position (400 or 500 mm) The second speed switch is then sets off. Wait 15 seconds for the speed to stabilize.




- 7 **Enter the setting mode again:** Press and hold for at least 3 seconds on release and press simultaneously on and shortly. The beep will then sound twice, and the red LED will flash. You are in the setting mode. The controller recognizes directly that you want to set the high speed.



- 8 Press on to increase the speed
Press on to decrease the speed


Once the anemometer measures a speed ≥ 0.4 m/s, the 0/10v setpoint is adjusted.

Each press increments the setpoint voltage by 0.5V over a range of 0.5V to 10V.



A press on increase the 0/10V reference sent to the drive.

A press on decrease the 0/10V reference sent to the drive.



9 IF DIGITAL DISPLAY MODEL

Press the push-button on the rear face to synchronize the speed reading on the anemometer and the speed displayed on the controller. One push increases by 0.1 m/s over a range of 0.3 à 0.7 m/s

10 Once the setting has been made, a long press on  allows to **both enter and exit the adjustment mode.**

The controller is now ready for use.

5. Factory rest

Press the push button on the electronic board for 15 seconds (the buzzer then rings 5 times to indicate that the procedure is working properly).

This procedure resets the factory settings: Setpoint and display to 0.5m/s, 7V analogue output and all relays and LEDs to off.



6. Test mode

“Test” mode confirms that all functions of the instrument are operational. To enter Test mode, Follow the procedure:

- 1** Press the 3 buttons simultaneously



Then the buzzer sounds twice.

- 2** Press the 3 buttons one after the other to check their correct operation:


- The buzzer sounds 3 times to indicate normal operation.
- The buzzer sounds 10 times if the function is faulty.

7. Change the audible alarm delay

It is possible on the rear face to change the buzzer's trigger time with the two switches.

- 1 = ON: Alarm still active
- 1 = OFF: Alarm disabled if ventilation is off
- 2 = ON: Delay set as 30s
- 2 = OFF: Delay set as 15s

ON
↕
OFF



8. Error messages (digital display option)

- The controller displays « **HI** » for a frontal speed greater than 0.8 m/s.
- The controller displays « **LO** » for a frontal speed lower than 0.2 m/s.
- The controller displays « **PB** » in case of speed sensor problem.

9. FAQ

Questions	Solutions
No indicators	Check that the power supply is correctly connected.
The fan does not start up	Check that the controllers ON button is fully engaged and that the yellow light above is on. Check wiring.
The display shows "PB"	Check that the speed sensor is correctly connected to the controller. Turn off and then restore power to the controller.
The light does not illuminate	The controller does not provide power, it provides a normally open contact. The light must be connected in the same way as if it were controlled by a switch.
The frontal speed is too low	Check the direction of rotation of the motor. Check that the system of installation is correct.
Front speed is too high	Check that the sizing of the installation is correct.
The display shows "8.8.8"	You are in Test mode: see the settings on page 12 to exit this mode.
The green LED is on and the red LED is flashing	You are in setting mode: see pages 11-12 to exit this mode.
The alarm sounds after a short time	Change the alarm delay with the CPU switches: see at the top of this page.
The speed does not change	Check with a voltmeter if the 0/10v output varies: <ul style="list-style-type: none"> - If it changes, check the drive connections. - If it does not change, check the correct positioning of the probe on the fume cupboard and carry out the adjustment procedure.



10. Maintenance

- Do not use abrasive materials.
- Avoid splashing liquid on the plastic box.
- Do not install the sensor on the extraction tube above the fume hood.
- Do not install the sensor in a dead zone of the fume hood.
- The sensor must not be subjected to air flow disturbances.
- The sensor must lead to the laboratory pressure.
- When setting up the controller, it is necessary that:
 - The fan is running
 - The lab must be completely closed (doors, windows, etc.)
 - Have an anemometer

11. Warranty

SEAT Ventilation guarantees that its equipment, products and parts are free from manufacturing defects under normal conditions of use for a period of two years after delivery to the first user. If a factory return is required within the two-year period from the date of purchase, contact your distributor. Products must be returned to the point of purchase with a dated invoice.



SEAT VENTILATION SAS
PARC TECHNOLOGIQUE DELTA SUD
09340 VERNIOLLE
France
E-mail: info@seat-ventilation.com
Site Web: www.seat-ventilation.com

